



## BIN PULL INSTALLATION

(1) Position Bin Pull on cabinet face and mark holes to be drilled.

(2) Using a 1/8" bit, drill 'pilot' holes through cabinet face where marked in step (1).

(3) Using a 1/4" bit, drill 7/16" deep into the 'pilot' holes in order to recess posts.

(4) Attach Bin Pull to cabinet using screws provided.