

# INSTRUCTIONS FOR INSTALLING

**STANLEY**<sup>®</sup>

## No. 150 Cafe Door Pivot Hinges - WITH HOLD OPEN FEATURE

(JUST FOLLOW THESE FOUR SIMPLE STEPS)

**STEP 4.** Set door into bottom pivot. Locate screw hole positions for top pivot, on jamb. Mount jamb section of hinge, allowing  $3/8$ " height between upper and lower hinge sections at pivot post (See diagram). This compensates for rise of door when swung into open position.

**STEP 1.** Mount top pivot to top of door,  $7/16$ " from finished back edge of door.

**STEP 2.** Mount bottom pivot to bottom of door,  $5/16$ " from finished back edge of door.

**STEP 3.** Mount bottom pivot to door jamb.  
NOTE: Bottom hinge requires  $7/8$ " of height.

**IMPORTANT!** Jamb section of upper hinge **MUST** be mounted with door in mounted position and with jamb hinge section over pivot post.

**STANLEY HARDWARE**

**Division of The Stanley Works  
New Britain, Connecticut**