


For construction with wall studs on 16 in. centers, the header is located between the studs for the right side mounting. For construction with wall studs on centers greater than 19-1/2 in. provide secure header as shown.

single gang box



www.ambaproducts.com Tel: 404-3509738

## Jeeves Model H Straight